Planting Tables - assembly

Use this guide with the dimensioned drawing and component schedule for your exact product code. Open all packages for the kit before starting.



Before you begin

Protect the finish with a clean, soft working surface. Identify the supplied fixings and use a driver bit that fits their heads. Wear gloves when handling metal edges. Bring in another person when positioning a larger assembly. Leave connections adjustable until the frame or footprint is square.

1. Identify the parts

Sort the four legs, perimeter rails, worktop pieces, lower-shelf pieces and 10 cm rear splashback. Use the drawing to distinguish the upper work surface from the lower storage shelf.

2. Build the frames

Assemble the perimeter rails for the main worktop and lower storage shelf. Fix the legs at the prepared positions, with two screws at each leg/frame connection.

3. Fit the lower storage surface

The lower shelf uses separate 20 x 100 mm aluminum profiles in both finishes. Align and secure the profiles to their supports.

4. Fit the main worktop

Classic uses separate aluminum profiles. Accoya fusion uses separate 20 x 100 mm Accoya boards. Keep the long edges aligned and fix the boards at their prepared support positions.

5. Attach the rear splashback

Fit the 10 cm-high rear panel. It is aluminum in Classic and 20 x 100 mm Accoya in Accoya fusion. The frame and legs remain aluminum.

6. Complete the base

Fit feet or the four supplied wheels according to the product code. Use the included wheel fixings. Engage any supplied brakes when stationary. Square the assembly and check every connection before use.

After assembly

Remove loose packing material. Check fixings and alignment after initial use and periodically thereafter. See the aluminum and Accoya care guides for cleaning. For replacement parts, quote the product code and identify the part on its drawing.

Products covered

Product code	Finish / option	Nominal dimensions and heights
BC-PT-S-01	Classic aluminum — without wheels	100 × 50 cm; levels 25 / 90 / 100 cm
BC-PT-A-01	Accoya fusion — without wheels	100 × 50 cm; levels 25 / 90 / 100 cm
BC-PT-S-02	Classic aluminum — without wheels	150 × 50 cm; levels 25 / 90 / 100 cm
BC-PT-A-02	Accoya fusion — without wheels	150 × 50 cm; levels 25 / 90 / 100 cm
BC-PT-S-03	Classic aluminum — without wheels	150 × 60 cm; levels 25 / 90 / 100 cm
BC-PT-A-03	Accoya fusion — without wheels	150 × 60 cm; levels 25 / 90 / 100 cm
BC-PT-S-01-W	Classic aluminum — with wheels	100 × 50 cm; levels 25 / 90 / 100 cm + wheel height
BC-PT-A-01-W	Accoya fusion — with wheels	100 × 50 cm; levels 25 / 90 / 100 cm + wheel height
BC-PT-S-02-W	Classic aluminum — with wheels	150 × 50 cm; levels 25 / 90 / 100 cm + wheel height
BC-PT-A-02-W	Accoya fusion — with wheels	150 × 50 cm; levels 25 / 90 / 100 cm + wheel height
BC-PT-S-03-W	Classic aluminum — with wheels	150 × 60 cm; levels 25 / 90 / 100 cm + wheel height
BC-PT-A-03-W	Accoya fusion — with wheels	150 × 60 cm; levels 25 / 90 / 100 cm + wheel height